



NINTENDO DS

Nintendo

**WARNING - HEALTH AND SAFETY**

BEFORE PLAYING, READ THE HEALTH  
AND SAFETY PRECAUTIONS booklet  
FOR IMPORTANT INFORMATION  
ABOUT YOUR HEALTH AND SAFETY.

TO GET AN EXTRA COPY SEE YOUR BOOK OR ASK AT  
[www.nintendo.com](http://www.nintendo.com)

Touch the Touch Screen to continue



Initialize config file ...

Create EVIK SAV file.

[A] Continue



EWIN OS V1.50R1

Ewin Team 2006

[C:]

[CP938]

1 (C).nds

Help: [Y] File Filter: [\*/] Open: [A]

EWIN OS V1.50R1

Ewin Team 2008

[CPO]

[CP888]

EWIN\_UPDATE.DAT

FONDIR.TXT

1 (C).nds

1 (C).sav

Help: [Y] File Filter: [X] Open: [A]

Warn! >>>DO NOT SWITCH OFF<<<

Danger!  
Update system loader?  
EWIN\_UPDATE.DAT

[B]Cancel

[A]Update

Erase...

It takes about 2 minutes. Pls wait...

Chip Erase

System Update

Congratulations!  
NDS will be switched off.

[A]Power off